

perfect fit blinds

fitting instructions

Assembly If you are to install your Perfect Fit blind personally, there is a simple assembly procedure to follow before fitting may commence.

Carefully unwrap the blind components. Unravel all guides and control cords. The blind will have the top and bottom parts of the frame attached together with a cable.

Lay out the blind face down on a clean, even surface.

Select the left hand frame component and guide onto the exposed arm of the bottom left corner joint. Slide the frame along the arm until secure. Repeat the process on the top left hand corner joint.

Once the frame is complete tighten the securing screws attached to each corner joint.

Your Perfect Fit blind is now ready to be fitted.

Fitting For the correct spacing distance (85mm) place a credit card into a corner of the window. (fig 1 - 3)

Line up the window fixing bracket at the base of the card (or top of the card depending upon which corner of the window you are working) and fit the bracket by pushing it between the glass and rubber seal on the window.

Using the credit card guarantees alignment of the bracket with the pre-punched holes in your frame.

Repeat the process until there are 2 window fixing brackets on each side of the window frame.

Attach the Perfect Fit frame on to the brackets. (fig 4)

fig 1



fig 2



fig 3



fig 4

