

# perfect fit pleated blinds

## fitting instructions

**Assembly** Carefully unwrap the blind components. Unravel all guides and control cords. The blind will have the top and bottom parts of the frame attached together with fine cable.

Lay out the blind face down on a clean, even surface.

Slide one side section into the top and bottom sections of the frame until secure, repeat this process for reverse side. Tighten locking screws to secure the frame.

Your Perfect Fit blind is now ready to be installed.

**Fitting** For the correct spacing distance (85mm) place a credit card into a corner of the window. (fig 1 - 3)

Line up the window fixing bracket at the base of the card (or top of the card depending upon which corner of the window you are working) and fit the bracket by pushing it between the glass and rubber seal on the window.

Using the credit card guarantees alignment of the bracket with the pre-punched holes in your frame.

Repeat the process until there are 2 window fixing brackets on each side of the window frame.

Attach the Perfect Fit frame on to the brackets. (fig 4)

fig 1



fig 2



fig 3



fig 4



NB: The manufacturer will not accept responsibility for damage to blinds caused by misuse. Fitting items may vary depending upon type of fitting requested.