

perfect fit venetian blinds

fitting instructions

Assembly Position the Perfect Fit frame face side down on a flat surface.

Slide one side frame section into the bottom and top sections of the frame until secure, repeat for reverse side. Tighten locking screws to secure the frame.

Carefully remove the packaging tape from around the blind whilst keeping the blind held together.

With the assembled frame still face down, push the headrail of the blind (the section with the main body of the blind attached) into the fixing brackets in the top section of the frame. Ensure this is centred and locked in place on all brackets.

Your Perfect Fit Blind is now ready to be installed.

Fitting For the correct spacing distance (85mm) place a credit card into a corner of the window. (fig 1 - 3)

Line up the window fixing bracket at the base of the card (or top of the card depending upon which corner of the window you are working) and fit the bracket by pushing it between the glass and rubber seal on the window.

Using the credit card guarantees alignment of the bracket with the pre-punched holes in your frame.

Repeat the process until there are 2 window fixing brackets on each side of the window frame.

Attach the Perfect Fit frame on to the brackets. (fig 4)

fig 1



fig 2



fig 3



fig 4



NB: The manufacturer will not accept responsibility for damage to blinds caused by misuse.
Fitting items may vary depending upon type of fitting requested.