

perfect fit blinds

measuring instructions

- fig. 1** Before you begin, ensure there is a clearance of 6mm all around the outside of your window beading to allow enough room for the Perfect Fit frame to fit.
- fig. 2 & 3** Measure the width and the drop of your glass size accurately (preferably with a digital measuring tape). We recommend that you measure in both corners and the middle of your window and use the smallest size taken.
- fig. 4** Measure the depth of the window using a depth gauge. If you do not have access to a depth gauge a ruler can be placed across the corner and then measure down to the glass.

This gives you the measurement from the face of the window frame to the glass (this is normally 18mm to 24mm) and will determine the size of the window fixing brackets you will use.

fig. 1



fig. 2



fig. 3



fig. 4



NB: The manufacturer will not accept responsibility for damage to blinds caused by misuse.
Fitting items may vary depending upon type of fitting requested.